

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓓ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio






Ⓟ Instrukcja montażu

Ⓔ Navod na montaž

Ⓡ Instrucțiuni de montaj

Ⓡ Инструкция по монтажу

36-4236-82-000







Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба



Name • Nom • Nome • Naam • Nazwa • Jméno • Názov
Név • Denumire • Isim • Название

Nr. • No. • N° • Č • Sz • Номер


Typ • Type • Tip • Tipus • Druh • Тиро • Тип




①	150110-82	x1
②	150210-82	x2




Ⓐ x1




Ⓑ (8x40)x4




Ⓒ (3x14x42)x2



Ⓓ (3x25)x4




① (3.5x35)x2






② (6x30) x2

1-000001=



		mm	
Ⓐ	1-000036-00	15g	x1
Ⓑ	1-000013-00	8x40	x4
Ⓒ	1-000154-07	14x42	x2
Ⓓ	1-000035-07	3,5x25	x4
①	1-000078-07	3,5x35	x2
②	1-000103-07	3,5x35	x2

576mm



a

b

c

